

## How to Use

# ACID Magic®

Muriatic Acid Replacement

## Cleaning Tile, Toilets, and Tubs



*ACID Magic is the easier way to remove stubborn mineral deposits from porcelain and tile. It can be used to remove calcium and scum build-up on tile, sinks, tubs, toilets and other non-porous, non-metal surfaces.*

**READ INSTRUCTIONS IN THEIR ENTIRETY BEFORE PROCEEDING.**

### PRECAUTIONS:

- Although ACID Magic is easier to use than hydrochloric/muriatic acid (HCl), protective eyewear and gloves are always required.
- Active ventilation is required when working indoors.
- **When diluting, ALWAYS add the ACID Magic to water, NOT water to the ACID Magic. This eliminates the potential of an unwanted reaction that may cause dangerous splashing to occur.**
- **Do not apply to dry surfaces.** Always wet surface prior to application, including any adjoining areas, in case of accidental spillage or overspray.
- **Do not allow the surface to dry with ACID Magic solution on it.**
- Use caution when applying ACID Magic to avoid contact with other surfaces, such as wood or metal, as an unwanted reaction and discoloration of surfaces could occur.

### FOR GENERAL CLEANING: DILUTION:

Dilute 1 part ACID Magic to 4 parts water.

### APPLICATION:

- Prepare a baking soda solution prior to application. Baking soda solution can be obtained by dissolving 2 - 4 parts sodium bicarbonate (baking soda) to 100 parts water.
- Wearing gloves, apply with acid resistant spray bottle or sponge. Lightly scrub surface with soft bristle brush or scouring pad. Rinse thoroughly with water. If second application is needed, repeat and rinse.
- **Rinse again with water.**
- Apply baking soda solution to surface to neutralize any remaining acid. Scrub with scouring pad.
- Flush thoroughly with water.

### FOR TOILETS AND URINALS:

**Toilet Bowls:** Simply add 6 - 8 ounces of ACID Magic to water in toilet bowl. Swish solution around in bowl with toilet brush, lightly scrubbing sides and under toilet rim to remove stains. Allow solution to sit in bowl for 3 - 5 minutes, then flush to rinse. Repeat if necessary to remove especially tough stains.

**For Urinals:** Remove strainer. Apply 6 - 8 ounces at top of urinal around water outlets using acid resistant spray bottle or sponge. Allow to sit for 5 minutes before continuing. Wearing gloves, gently scrub surface with **natural**, soft bristle brush or scouring pad. Flush to rinse. Tougher stains may require repeat application.

